

Location	Part Number	Type	Description
PF2025	CHCAB00034		Chassis frame
PF2025	CHCAB00035		Back cover
PF2025	CHCAB00036		Front cover assembly
PF2025	CHCAB00037		Six-button
PF2025	CHCBA00036	Main board	Main board
PF2025	CHCBA00037	CRT Board, Y Board	CRT Board, Y Board
PF2025	CHCBA00038	AV BOARD	AV BOARD
PF2025	CHCBA00039	K BOARD	K BOARD
PF2025	CHCBA00040	Remote board	Remote board
VE901	CHCRT00007	A51QDX992X001	21" CRT
NY01	CHICS00063	TDA6107Q	IC
PF2025	CHSPK00011	YDT513-A3-10W-8ohm	Electric speaker
A101	CHTNR00002	TDQ-6F2-M	Electronic tuner
T402	CHTRF00029	BSC62B	FBT
V432	CHTRS00009	2SC2688-L	Triode
V512	CHTRS00011	2SC3807	Triode
V513	CHTRS00014	2SC4423-M	Triode
PF2025-3225	CHCBA00043	D-Com Board	Digital Com Filter Board
PF2025-3225	CHCBA00046	VM Board	VM Board
PF2025-3225	CHCBA00049	BTSC Board	BTSC Stereo Board
PF2425	CHCAB00038		Chassis frame
PF2425	CHCAB00039		Back cover
PF2425	CHCAB00040		Front cover assembly
PF2425	CHCBA00041	Main board	Main board
PF2425-3225	CHCBA00035	Power board	Power board
PF2425-3225	CHCBA00042	CRT Board	CRT Board, Y Board
PF2425-3225	CHCBA00044	AV BOARD	AV BOARD
PF2425-3225	CHCBA00045	AV Board Side	AV Board Side
PF2425-3225	CHCBA00047	K BOARD	K BOARD
PF2425-3225	CHCBA00048	Remote board	Remote board
SY01	CHCNT00019	GZS10-2-108A	GZS CRT socket
SY01	CHCNT00020	GZS10-2-AC3	GZS CRT socket
SY01	CHCNT00022	GZS10-301-2	GZS CRT socket
SY01	CHCNT00023	GZS10-301-G2	GZS CRT socket
XS01	CHCNT00030	AV-3S-9PB	AY terminals
XS02	CHCNT00031	AV-2-6PA	AY terminals
XS01	CHCNT00032	AV-1-3PNC	AV terminals
XS01	CHCNT00033	AVL-13-3RA	AV terminals
AY01	CHCRT00011	A59QDC259X542.	25" CRT
AY01	CHCRT00012	A59QDF891X002	25" CRT
AY01	CHCRT00012	A59QDF891X002	25" CRT
AY01	CHCRT00016	A68QCP891X001	31 " CRT
AY01	CHCRT00019	A68QDL080X013	32 " CRT
AY01	CHCRT00020	A80LTM350X10	34" CRT
AY01	CHCRT00021	A80QEA891X001	34" CRT
AY01	CHCRT00031	A68QCL259X550	29 " CRT
AY01	CHCRT00031	A68QCL259X550	30 " CRT
Z650M	CHCRY00002	JA18A1-18.432MHz	Crystal oscillator
Z202	CHCRY00004	JA18A1-3.579545MHz	Crystal oscillator
PF2425-3225	CHCRY00004	JA18A1-3.579545MHz	Crystal oscillator
Z001	CHCRY00008	JA18D-32.768KHz	Crystal oscillator
PF2425-3225	CHCRY00008	JA18D-32.768KHz	Crystal oscillator
VD821	CHDIO00012	AK03	Diode

Location	Part Number	Type	Description
VD821	CHDIO00012	AK03	Diode
VD824	CHDIO00013	AU01Z	Diode
VD82SA	CHDIO00013	AU01Z	Diode
VD828	CHDIO00013	AU01Z	Diode
VD824	CHDIO00013	AU01Z	Diode
VD825A	CHDIO00013	AU01Z	Diode
VD828	CHDIO00013	AU01Z	Diode
VD402	CHDIO00014	BAV21	Diode
VD443	CHDIO00014	BAV21	Diode
VD475	CHDIO00014	BAV21	Diode
VD402A	CHDIO00014	BAV21	Diode
VDY01A	CHDIO00014	BAV21	Diode
VDY02A	CHDIO00014	BAV21	Diode
VDY03A	CHDIO00014	BAV21	Diode
VD402	CHDIO00014	BAV21	Diode
VD443	CHDIO00014	BAV21	Diode
VD475	CHDIO00014	BAV21	Diode
VD402A	CHDIO00014	BAV21	Diode
VD433	CHDIO00017	BY359F-1500	Diode
VD433	CHDIO00017	BY359F-1500	Diode
VD801	CHDIO00018	BY56	Diode
VD802	CHDIO00018	BY56	Diode
VD803	CHDIO00018	BY56	Diode
VD804	CHDIO00018	BY56	Diode
DM007	CHDIO00020	BYV26C	Diode
DM008	CHDIO00020	BYV26C	Diode
VD434	CHDIO00022	BYW96D	Diode
PF2425-3225	CHDIO00022	BYW96D	Diode
VD434	CHDIO00023	BYW96E	Diode
PF2425-3225	CHDIO00023	BYW96E	Diode
VD401A	CHDIO00024	BZD23-C33	Diode
VD401A	CHDIO00024	BZT03-C33	Diode
VD401A	CHDIO00024	BZD23-C33	Diode
VD401A	CHDIO00024	BZT03-C33	Diode
VD829	CHDIO00037	MTZJ24C	Diode
VD829	CHDIO00037	MTZJ24C	Diode
VD835	CHDIO00052	RU4AM(LF-LI)	Diode
VD835	CHDIO00052	RU4AM(LF-LI)	Diode
VD822	CHDIO00053	SARS01	Diode
VD822	CHDIO00053	SARS01	Diode
VD826	CHDIO00063	W05Z18C	Diode
VD827	CHDIO00063	W05Z18C	Diode
VD826	CHDIO00063	W05Z18C	Diode
VD827	CHDIO00063	W05Z18C	Diode
VD829	CHDIO00064	W05Z24C	Diode
VD008	CHDIO00065	W05Z3.6A	Diode
PF2425-3225	CHDIO00065	W05Z3.6A	Diode
VD6S0M	CHDIO00068	W05Z4.3A	Diode
VDY30	CHDIO00069	W05Z5.1B	Diode
VD836	CHDIO00074	W05Z6.8B	Diode
VD439	CHDIO00076	W05Z8.2B	Diode
PF2425-3225	CHDIO00076	W05Z8.2B	Diode
VD801	CHDIO00078	Z5A6	Diode

Location	Part Number	Type	Description
VD802	CHDIO00078	Z5A6	Diode
VD803	CHDIO00078	Z5A6	Diode
VD804	CHDIO00078	Z5A6	Diode
VD801	CHDIO00078	Z5A6	Diode
VD802	CHDIO00078	Z5A6	Diode
VD803	CHDIO00078	Z5A6	Diode
VD804	CHDIO00078	Z5A6	Diode
VD801	CHDIO00078	Z5A6	Diode
VD802	CHDIO00078	Z5A6	Diode
VD803	CHDIO00078	Z5A6	Diode
VD804	CHDIO00078	Z5A6	Diode
VDK01	CHDIO00080	W05Z5.6A	Diode
VDK01	CHDIO00080	W05Z5.6A	Diode
DM003	CHDIO00081	W05Z12C	Diode
T801	CHFTR00001	LCL-F11 (JU4.757.030)	Line filter
T801	CHFTR00001	LCL-F11(JU4.757.060)	Line filter
T802	CHFTR00003	TRF3196	Line filter
T802	CHFTR00003	TRF3196	Line filter
Z101	CHFTR00009	M1958M	Surface acoustic wave filter
PF2425-3225	CHFTR00009	M1958M	Surface acoustic wave filter
Z102	CHFTR00010	M3953M	Surface acoustic wave filter
Z103	CHFTR00011	M9352M	Surface acoustic wave filter
Z601	CHFTR00014	TPSRA4M50B00-B0	Ceramic trap
PF2425-3225	CHFTR00014	TPSRA4M50B00-B0	Ceramic trap
Z601	CHFTR00017	XT4.5MB	Ceramic trap
PF2425-3225	CHFTR00017	XT4.5MB	Ceramic trap
ZP831	CHFUS00001	PRF5000F008	Direct—weld fuse
ZP832	CHFUS00001	PRF5000F008	Direct—weld fuse
ZP833	CHFUS00001	PRF5000F008	Direct—weld fuse
PF2425-3225	CHFUS00001	PRF5000F008	Direct—weld fuse
PF2425-3225	CHFUS00001	PRF5000F008	Direct—weld fuse
PF2425-3225	CHFUS00001	PRF5000F008	Direct—weld fuse
N002	CHICS00004	AT24C08-10PI	IC
PF2425-3225	CHICS00004	AT24C08-10PI	IC
N001	CHICS00009	CH04T1004	IC
PF2425-3225	CHICS00009	CH04T1004	IC
PF2425-3225	CHICS00016	CW574CS	IC
NP02	CHICS00019	HEF4053BP	IC
PF2425-3225	CHICS00019	HEF4053BP	IC
PF2425-3225	CHICS00019	MC14053BCP	IC
NK07	CHICS00021	HS0038	IC
NK07	CHICS00021	HS0038	IC
NK07	CHICS00021	HS0038	IC
NK03	CHICS00021	HS0038	IC
NK07	CHICS00022	HS0038A	IC
NK07	CHICS00022	HS0038A	IC
NK07	CHICS00022	HS0038A	IC
NK03	CHICS00022	HS0038A	IC
NK07	CHICS00023	HS0038A2	IC
NK07	CHICS00023	HS0038A2	IC
NK07	CHICS00023	HS0038A2	IC
NK03	CHICS00023	HS0038A2	IC
VD114	CHICS00026	KA33V	IC

Location	Part Number	Type	Description
PF2425-3225	CHICS00026	KA33V	IC
N862	CHICS00027	L7805CV	IC
PF2425-3225	CHICS00027	L7805CV	IC
PF2425-3225	CHICS00027	MC7805CT	IC
N851	CHICS00030	L78L05ACZ	IC
PF2425-3225	CHICS00030	L78L0SACZ	IC
N851	CHICS00030	L78L05ACZ	IC
N402	CHICS00037	LM317T	IC
N852	CHICS00037	LM317T	IC
	CHICS00037	LM317T	IC
	CHICS00037	LM317T	IC
NQ838	CHICS00038	LTV-816A	IC
	CHICS00038	LTV-816A	IC
N606M	CHICS00045	MSP3440G-B8	IC
N301	CHICS00048	OM8839PS	IC
	CHICS00048	OM8839PS	IC
	CHICS00048	p~A78L05ACLP	IC
NQ833	CHICS00052	SE135N	IC
NQ833	CHICS00052	SE135N	IC
NQ833	CHICS00053	SE140N	IC
NQ821	CHICS00057	STR-F6626	IC
NQ821	CHICS00057	STR-F6626	IC
DS01	CHICS00059	TA1219AN	IC
N103	CHICS00060	TA78L009AP	IC
DS02	CHICS00060	TA78L009AP	IC
PF2425-3225	CHICS00060	TA78L009AP	IC
NY01	CHICS00064	TDA6108JF	IC
N601	CHICS00066	TDA7057AQ	IC
PF2425-3225	CHICS00066	TDA7057AQ	IC
N401	CHICS00067	TDA8350Q-N6	IC
PF2425-3225	CHICS00067	TDA8350Q-N6	IC
N301	CHICS00070	TDA8843-N2	IC
PF2425-3225	CHICS00070	TDA8843-N2	IC
NQ102	CHICS00074	TDA9808/V4	IC
NQ102	CHICS00074	TDA9808/V3	IC
N851	CHICS00076	uA78L05ACLP	IC
N851	CHICS00076	uA78L05ACLP	IC
VD114	CHICS00079	uPC574J	IC
PF2425-3225	CHICS00079	uPC574J	IC
NK03	CHICS00084	MM1031XS	IC
NK03	CHICS00084	MM1031XS	IC
NK02	CHICS00085	TC90A53N	IC
NK02	CHICS00085	TC90A53N	IC
XP910A	CHIND00003	XC-25	Degaussing coil
L433	CHIND00010	HXT20D(JU4.756.033)	Horizontal linear coil
L433	CHIND00011	HXT25(JU4.756.038)	Horizontal linear coil
L433	CHIND00011	HXT25(JU4.756.038)	Horizontal linear coil
L433	CHIND00012	HXT30(JU4.756.022)	Horizontal linear coil
L433	CHIND00012	HXT30(JU4.756.022)	Horizontal linear coil
L433	CHIND00012	HXT30(JU4.756.022)Add the foil	Horizontal linear coil
L433	CHIND00012	HXT30(JU4.756.022)	Horizontal linear coil
T434	CHIND00043	LGT-1.5mH-K	Fixed inductor
L433A	CHIND00044	LGT-100uH-K	Horizontal amplitude inductor

Location	Part Number	Type	Description
L433A	CHIND00046	LGT-150uH-K	Horizontal amplitude inductor
L433A	CHIND00048	LGT-50uH(JUB4.757.007)	Horizontal amplitude inductor
XP910A	CHIND00065	XC-29	Degaussing coil
XP910A	CHIND00065	XC-29	Degaussing coil
XP910A	CHIND00066	XC-34	Degaussing coil
L433A	CHIND00069	WT-150uH-K	Horizontal amplitude inductor
VDK03	CHLED00001	FG5RD	Diode
VDK03	CHLED00001	FG5RD	Diode
PF2425-3225	CHRES00367	R140-0.5W-1.5KohmK	Glass glazed resistor
BC601	CHSPK00002	YDT516-A1-10W-8ohm	Electric speaker
BC602	CHSPK00002	YDT516-A1-10W-8ohm	Electric speaker
PF2425-3225	CHSPK00002	YDT516-A1-10W-8ohm	Electric speaker
PF2425-3225	CHSPK00002	YDT516-A1-10W-8ohm	Electric speaker
BC603	CHSPK00006	YDT813-C6-10W-8ohm	Electric speaker
BC604	CHSPK00006	YDT813-C6-10W-8ohm	Electric speaker
BC601	CHSPK00010	YDG41-A1-10W-8ohm	Electric speaker
BC602	CHSPK00010	YDG41-A1-10W-8ohm	Electric speaker
KK01	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK02	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK03	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK04	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK05	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK06	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK01	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK02	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK03	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK04	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK05	CHSWT00002	KA1L6x5x7.5-22	Feather touch switch
KK06	CHSWT00002	KA1L6x5x75-22	Feather touch switch
S801	CHSWT00006	KDC-A04-MU171	Power switch
S801	CHSWT00006	KDC-A04-MU171	Power switch
A101	CHTNR00002	TDQ-6F2-M	Electronic tuner
PF2425-3225	CHTNR00002	TDQ-6F2-M	Electronic tuner
T431	CHTRF00007	BCT-8(JUB4.739.003)	Line drive transformer
T431	CHTRF00007	BCT-8(JUB4.739.003)	Line drive transformer
T862	CHTRF00013	BCK-24907L(JUB4.726.102)	Switch transformer
T862	CHTRF00013	BCK-24907L(JUB4.726.102)	Switch transformer
T862	CHTRF00014	BCK-24908L(JUB4.726.103)	Switch transformer
T402	CHTRF00021	BSC68E	FBT
T402	CHTRF00022	BSC70C(JU4.799.024-6)	FBT
T402	CHTRF00022	BSC70C(JU4.799.024-6)	FBT
T402	CHTRF00025	BSC73H	FBT
T402	CHTRF00026	BSC73J	FBT
VY02	CHTRS00006	2SC2482	Triode
VQ821	CHTRS00008	2SC2655-Y	Triode
VQ821	CHTRS00008	2SC2655-Y	Triode
VQ002	CHTRS00010	2SC2878-A	Triode
vpoos	CHTRS00010	2SC2878-A	Triode
VQ002	CHTRS00010	2SC2878-A	Triode
VQ005	CHTRS00010	2SC2878-A	Triode
V104	CHTRS00013	2SC388ATM	Triode
	CHTRS00013	2SC388ATM	Triode
V101	CHTRS00013	2SC388ATM	Triode

Location	Part Number	Type	Description
VQ020	CHTRS00018	2SC4793	Triode
VQ020	CHTRS00018	2SC4793	Triode
YQ007	CHTRS00033	BC547	Triode
VQ009	CHTRS00033	BC547	Triode
VQ010	CHTRS00033	BC547	Triode
VQ020	CHTRS00033	2SD2400A,E	Triode
VQ007	CHTRS00033	BC547	Triode
VQ009	CHTRS00033	BC547	Triode
VQ010	CHTRS00033	BC547	Triode
VQ020	CHTRS00033	2SD2400A,E	Triode
V0008	CHTRS00034	BC557	Triode
VQ011	CHTRS00034	BC557	Triode
VQ008	CHTRS00034	BC557	Triode
VQ011	CHTRS00034	BC557	Triode
VY01	CHTRS00036	BF422	Triode
V432	CHTRS00037	BSN274	Field effect transistor
PF2425-3225	CHTRS00037	BSN274	Field effect transistor
V432	CHTRS00038	BSN304	Field effect transistor
PF2425-3225	CHTRS00038	BSN304	Field effect transistor
V433	CHTRS00040	BU2720DX	Triode
PF2425-3225	CHTRS00040	BU2720DX	Triode
PF2425-3225	CHTRS00043	KSC388C-Y	Triode
V101	CHTRS00043	KSC388C-Y	Triode
V862	CHTRS00045	RN1204	Triode
VQ822	CHTRS00045	RN1204	Triode
VS08	CHTRS00045	RN1204	Triode
VS09	CHTRS00045	RN1204	Triode
V862	CHTRS00045	RN1204	Triode
VQ822	CHTRS00045	RN1204	Triode
PF2425-3225	CHWIR00012	RVVZ-CH2-ZA720-ZH1	Power cord
XS801	CHWIR00012	RVVZ-CH2-ZA720-ZH1	Power cord
XS801	CHWIR00013	RWZ-CH2--W240-ZH1	Power cord
PF2725	CHCAB00041		Six-button
PF2725	CHCAB00042		Bear plate
PF2725	CHCAB00043		Back cover
PF2725	CHCAB00044		Front cover
PF2725	CHCAB00045		Chassis assembly
PF2725	CHCBA00050	Main board	Main board
PF3225	CHCAB00046	JUC8.604.023	Right speaker holder
PF3225	CHCAB00047	JUC8.604.022	Left speaker holder
PF3225	CHCAB00048	JUC8.070.026	Base plate
PF3225	CHCAB00049	JUC6.356.011	Six-button assembly
PF3225	CHCAB00050	JUC6.116.511	Back cover assembly
PF3225	CHCAB00051	JUC6.116.506	Front cover assembly
PF3225	CHCAB00052	JUC5.049.170	Chassis assembly
PF3225	CHCAB00053	JU6.152.259	CRT Support
PF3225	CHCBA00051	Main board	Main board
	CHMSC00004	WARNING LABEL	WARNING LABEL
	CHMSC00005	SCREWS	SCREWS